

Brand	Standard	ECU	MEMORY OPERATION				Keys	Calc	Extra
			Flash/EEPROM	OBD	DC	Boot			
Iveco	Euro3-5	VCM2	Read/Write		+	+		Pin code	
Iveco	Euro3-5	VCM3	Read/Write			+			
Iveco	Euro3-5	EDC7UC31	Read/Write	+	+	+			
Iveco	Euro6	EDC17C41	Read/Write	+	+	+			
MAN	Euro3-5	FFR	Read/Write	+	+	+	Pairing, Add key		Speed limit, Torque limit and other parametrs
MAN	Euro3-5	EDC7C32	Read/Write	+	+	+			VIN code and other parameters
MAN	Euro6	PTM	Read/Write	+	+	+	Pairing, Add key		Speed limit, Torque limit and other parametrs
MAN	Euro6	EDC17C42	Read/Write	+	+	+			
Mercedes	Euro3-5	MR	Read/Write	+	+	+	IMMO OFF, Add key	VEDOC, DAS password	Unlock/Lock, Parametrs, Emmission Fault clear
Mercedes	Euro3-5	MR2	Read/Write	+	+	+	IMMO OFF, Add key	VEDOC, DAS password	Unlock/Lock, Parametrs, Emmission Fault clear
Mercedes	Euro3-5	ADM3	Read/Write		+	+			Speed limit change in ADM3
Mercedes	Euro3-5	FR	Read/Write	+	+	+	IMMO OFF		Speed limit, Parametrs
Mercedes	Euro3-5	CPC	Read/Write	+	+	+	IMMO OFF		Speed limit, Torque limit
Mercedes	Euro3-5	CPC4	Read/Write	+	+	+			
Mercedes	Euro3-5	EHZ	Read/Write		+	+			
Mercedes	Euro3-5	GSII	Read/Write		+	+			
Mercedes	Euro6	MCM	Read/Write	+	+	+	Unpair/Pair; Switch FBS3/Classic; Add key (transponder)	VEDOC	
Mercedes	Euro6	MCM2	Read/Write	+	+	+	Unpair/Pair; Switch FBS3/Classic; Add key (transponder)	VEDOC	
Mercedes	Euro6	MCM2.1	Read/Write	+	+	+	Unpair/Pair; Switch FBS3/Classic; Add key (transponder)	VEDOC	
Mercedes	Euro6	MCM2.1 D4	Read/Write	+	+	+	Unpair/Pair; Switch FBS3/Classic; Add key (transponder)	VEDOC	Unlock/Lock
Mercedes	Euro6	ACM2	Read/Write	+	+	+		VEDOC	Torque limit
Mercedes	Euro6	ACM2.1	Read/Write	+	+	+		VEDOC	Torque limit
Mercedes	Euro6	ACM2.1 D4	Read/Write	+	+	+		VEDOC	Torque limit
Mercedes	Euro6	CPC3	Read/Write		+	+			Speed limit
Mercedes	Euro6	CPC3Evo	Read/Write			+			
Mercedes	Euro6	TCM					Unpair/Pair		
Mercedes	all	all						FDOK	
Scania	Euro3-5	COO7	Read/Write			+			

+ - available
 + - soon